

How to Update the Main Board by Program Writer


Step 1 : Turn off the machine. Find out the Program Writer Hardware and connect it with the computer and machine main board.






Step 2 : Find out the Program Writer Software and open it.







Step 3 : Adjust the settings as per the image.



Step 4 : Click Open Code File and select the latest version file.




Step 5 : Click Download/Program button.



Step 6 : When there is new window appears, click OK.



Step 7 : When “Re-Cecking target MCU” shows in software, power on the machine.



Step 8 : After few seconds, “Complete” shows in software with Beeps from the machine, restart the machine.



NOTE: Do not press General Power Button too often, we need to wait at least 10 seconds before press it again.